
CAUTIONS AND WARNINGS:

- This product must be installed in accordance with the applicable installation code by a licensed electrician familiar with the construction and operation of the product and hazards involved.
- Power must be OFF when connecting the fixture. "Hot plugging" the light engine and driver will damage the LED source.
- 3. The light engine is low voltage and is factory wired to the driver.

 DO NOT CONNECT LIGHT ENGINE TO THE BUILDING AC POWER.

<u>DISCLAIMER:</u> Screw and hardware on the outer edge of adjustable head are **NOT** to be tampered with. **ANY** adjustment **WILL VOID** warranty.



Anchor mounting rails into joists with screws.
Slide Bracket Pan with butterfly brackets
into mounting rails. Clip mounting rails to secure.



SLOTTED FLAP
allows for 90° swap
of Butterfly bracket &
Mounting rails for
narrower joist spacing

Bottom of bracket pan should either be flush with bottom of ceiling joists or 1/8" higher than bottom of joists.



