

CAUTIONS AND WARNINGS:

1. This product *must* be installed in accordance with the applicable installation code by a licensed electrician familiar with the construction and operation of the product and hazards involved.
2. Power *must* be **OFF** when connecting the fixture. "Hot plugging" the light engine and driver will damage the LED source.
3. The light engine is low voltage and is factory wired to the driver.
DO NOT CONNECT LIGHT ENGINE TO THE BUILDING AC POWER.

DISCLAIMER: Screw and hardware on the outer edge of adjustable head are **NOT** to be tampered with. **ANY** adjustment **WILL VOID** warranty.



A Install New Pan into ceiling joists. Continue installing ceiling drywall. (New pan is reversible)



B Apply Tape and joint compound. Cutout opening and prep for painting ceiling.



C Slide Flange receiver into opening.



E Finalize electrical wiring/connections. Then slide light assembly into receiver.

90° Adjustable Clamp on receiver (retractable)



CLOSEUP
Use a Phillips screwdriver to adjust height of the ceiling clamp to secure a tight fit between GWB ceiling and light fixture.



D Tighten screws to clamp receiver to ceiling



F Ball plungers(4) on light assembly clicks into 4 slots on receiver.



G After light assembly locks into the flanged receiver, slide & lock flanged trim into the receiver.



IMPORTANT
Ball Plungers on round flanged trim and light assembly needs to click into receiver

*Trim in view is GR- Round Flanged Trim

How to secure with safety cables?



Repeat process for all GR-Round Flanged.

Installation Instructions for Retrofit Round Flanged Trim GRF, GR, GRO, GRW

TRIMS AVAILABLE



GRAFFITI
LIGHTING
by: Specialty Lighting Industries