

## CAUTIONS AND WARNINGS:

1. This product *must* be installed in accordance with the applicable installation code by a licensed electrician familiar with the construction and operation of the product and hazards involved.
2. Power *must* be **OFF** when connecting the fixture. "Hot plugging" the light engine and driver will damage the LED source.
3. The light engine is low voltage and is factory wired to the driver.  
**DO NOT CONNECT LIGHT ENGINE TO THE BUILDING AC POWER.**

**DISCLAIMER:** Screw and hardware on the outer edge of adjustable head are **NOT** to be tampered with. **ANY** adjustment **WILL VOID** warranty.



**A** Install New Pan into ceiling joists. Continue installing ceiling drywall. (New pan is reversible)



**B** Apply Tape and joint compound. Cutout opening and prep for painting ceiling.



**C** Cutout opening for light install.



**E** Plaster receiver flange. Finish electrical



**G** After plaster ceiling has dried, paint over the plaster ceiling.



**D** Attach receiver with GWB screws (4). \*See Closeup- tighten receiver to GWB Ceiling.

**F** Slide light assembly into receiver. Finish plastering GWB.



**H** Make sure trim ball plungers clicks into receiver to secure.

### How to secure with safety cables?



## Installation Instructions for New Pan Plaster Receiver GRF, GR, GRO, GRW

### TRIMS AVAILABLE

