
CAUTIONS AND WARNINGS:

- 1. This product *must* be installed in accordance with the applicable installation code by a licensed electrician familiar with the construction and operation of the product and hazards involved.
- Power must be OFF when connecting the fixture. "Hot plugging" the light engine and driver will damage the LED source.
- 3.The light engine is low voltage and is factory wired to the driver.

 DO NOT CONNECT LIGHT ENGINE TO THE BUILDING AC POWER.

<u>DISCLAIMER:</u> Screw and hardware on the outer edge of adjustable head are **NOT** to be tampered with. **ANY** adjustment **WILL VOID** warranty.












by: Specialty Lighting Industries







Push-pin fastener locks

trim safety cable trim to

lamp assembly